

# ISOLOG 3D MOBILE PRO

## Quick Guide



- 1** X-axis sensor
- 2** Y-axis sensor
- 3** Z-axis sensor
- 4** Power on/off
- 5** Select axis  
X/Y/Z-axis or chop-mode (rotates around X/Y/Z axis)
- 6** Select chop rate  
1 Hz up to 50 kHz (adjustable in 16 steps)
- 7** Preamp 1 on / Preamp 2 on / Both off
- 8** Select sensor  
Loop for lower / dipole for higher frequency range
- 9** LED's  
X/Y/Z red = active sensor or alternating for chop mode  
SENSOR green = loop / red = dipole  
PREAMP blink = one on / red = both on / black = off  
REMOTE red = connected to PC  
BATTERY red = charging / green = charged
- 10** N-Type rf connector  
female / optional male
- 11** Power connector  
For battery charging with included 12V power supply